

Lecture 9

Photogeneration, Absorption, and Nonequilibrium

Reading:



(Cont'd) Notes and Anderson² sections 3.4-3.11

Photogeneration


Light with photon energy, $h\nu < E_g$ is not easily absorbed. A convenient expression for the energy of light is $E=1.24/\lambda$ where λ is the wavelength of the light in μm .

Light with energy, $h\nu > E_g$ is absorbed with the “unabsorbed” light intensity as a function of depth into the semiconductor is $I(x) = I_0 e^{-\alpha x}$

where I_0 is the initial light intensity, x is distance and α is the absorption coefficient [1/cm].



Photogeneration



Photogeneration

Each Photon with energy greater than E_g can result in one electron hole pair. Thus, we can say,

$$\left. \frac{\partial n}{\partial t} \right|_{\text{Light}} = \left. \frac{\partial p}{\partial t} \right|_{\text{Light}} = G_L(x, \lambda) \quad \text{where } G_L(x, \lambda) = G_{L0} e^{-\alpha x} \quad \# / (cm^3 - Sec)$$

If α is small (near bandgap light), the generation profile can be approximately constant.

If α is large (light with energy \gg bandgap), the generation profile can be approximated as at the surface.

Important Nomenclature

n_0, p_0	...	carrier concentrations in the material under analysis when equilibrium conditions prevail.
n, p	...	carrier concentrations in the material under arbitrary conditions.
$\Delta n \equiv n - n_0$...	deviations in the carrier concentrations from their equilibrium values.
$\Delta p \equiv p - p_0$		Δn and Δp can be both positive and negative, where a positive deviation corresponds to a carrier excess and a negative deviation corresponds to a carrier deficit.
N_T	...	number of R-G centers/cm ³ .

$$n = \Delta n + n_0 \text{ and } p = \Delta p + p_0$$



In Non-equilibrium, np does not equal n_i^2

Low Level Injection

$\Delta p = \Delta n \ll n_0$ and $n \sim n_0$ in n-type material

$\Delta p = \Delta n \ll p_0$ and $p \sim p_0$ in p-type material

Carrier Concentrations after a “Perturbation”



Δp can be $\gg p_0$

If $\Delta p \gg p_0$, $p \sim \Delta p$

After the carrier concentrations are perturbed by some stimulus (leftmost case) and the stimulus is removed (center case) the material relaxes back toward its equilibrium carrier concentrations.

Material Response to “Non-Equilibrium”: Relaxation Concept

Consider a case when the hole concentration in an n-type sample is not in equilibrium, i.e., pn does NOT equal n_i^2

$$\left. \frac{\partial p}{\partial t} \right|_{\text{thermal R-G}} = -\frac{\Delta p}{\tau_p} \quad \text{where} \quad \tau_p = \frac{1}{c_p N_T}$$

where τ_p is the minority carrier lifetime

c_p is a proportionality constant

N_T is the "trap" concentration

- The minority carrier lifetime is the average time a minority carrier can survive in a large ensemble of majority carriers.
- If Δp is negative \rightarrow Generation or an increase in carriers with time.
- If Δp is positive \rightarrow Recombination or a decrease in carriers with time.
- Either way the system “tries to reach equilibrium”
- The rate of relaxation depends on how far away from equilibrium we are.

Material Response to “Non-Equilibrium”: Relaxation Concept

Likewise when the electron concentration in an p-type sample is not in equilibrium, i.e., pn does NOT equal n_i^2

$$\left. \frac{\partial n}{\partial t} \right|_{\text{thermal R-G}} = -\frac{\Delta n}{\tau_n} \quad \text{where} \quad \tau_n = \frac{1}{c_n N_T}$$

where τ_n is the minority carrier lifetime
 c_n is a different proportionality constant
 N_T is the "trap" concentration

More generally for any doping case:

$$\left. \frac{\partial n}{\partial t} \right|_{\text{thermal R-G}} = \left. \frac{\partial p}{\partial t} \right|_{\text{thermal R-G}} = \frac{n_i^2 - np}{\tau_p(n + n_1) + \tau_n(p + p_1)} \quad \left. \vphantom{\frac{\partial n}{\partial t}} \right\} \text{Same unit as above}$$


where...

$$n_1 \equiv n_i e^{(E_T - E_i)/kT} \quad \text{and} \quad p_1 \equiv n_i e^{(E_i - E_T)/kT}$$

Example: After a long time on, a light is switched off

$$\frac{\partial n}{\partial t} = -\frac{\Delta n}{\tau_n} \quad \text{has a solution}$$

$$n(t) = n_o + \underbrace{\Delta n_o e^{-\left(\frac{t}{\tau_n}\right)}}_{\Delta n(t)} \quad \text{where } \Delta n_o = \text{initial excess electron concentration}$$



Material Response to “Non-Equilibrium”: Relaxation Concept

Carrier Relaxation can also be achieved through Direct recombination

Given: $\Delta n = \Delta p$, $n = n_o + \Delta n$, $p = p_o + \Delta p$

Low Level Injection $\implies \Delta n \ll N_a$ and High Level Injection $\implies \Delta n \gg N_a$

• Recombination Rate, $R = Bnp$ [# / cm³ sec.] (depends on number of electrons and holes present)

• In Thermal Equilibrium,

$np = n_i^2$ where n_i^2 is the n-p product due to thermal generation (intrinsic generation)

Recombination rate, $R = B n_i^2 = G$, Generation Rate where B is a constant

Under Illumination (Non-thermal equilibrium), $np \neq n_i^2$

Net Recombination Rate, $-dn/dt = R - G = B(np - n_i^2)$

but,

$\Delta n = \Delta p$

$$-dn/dt = B(np - n_i^2)$$

$$= B((n_o + \Delta n)(p_o + \Delta p) - n_i^2)$$

$$= B(n_o p_o - n_i^2 + \Delta p n_o + \Delta n p_o + \Delta n \Delta p)$$

$$= B\Delta n(0 + n_o + p_o + \Delta n)$$

$$= B\Delta n(n_o + p_o + \Delta n)$$

Thus, using our lifetime definition,

$$-dn/dt = -\Delta n / \tau_e$$

$$\tau_e = 1 / (B(n_o + p_o + \Delta n))$$

Material Response to “Non-Equilibrium”: Relaxation Concept

Carrier Relaxation can also be achieved through Direct recombination

Special cases:

Low Level Injection: $\Delta n \ll \text{majority carrier density}$

$$\tau_e = 1 / (B(n_o + p_o))$$

and if the material is n-type:

$$\tau_e = 1 / (Bn_o)$$

or p-type:



$$\tau_e = 1 / (Bp_o)$$

High level injection: $\Delta n \gg \text{majority carrier density}$


$$\tau_e = 1 / (B\Delta n)$$

Optional

Electron Capture and Emission



Hole Capture and Emission



How many holes are available for capture

Number of filled defect sites


$$c_p = v_{th,p} \sigma_p p N_t f(E)$$

Capture cross section: Effective size of the defect. Units of area

Thermal velocity: How fast the holes are moving

Hole Capture Rate

Optional



Number of empty defect sites

$$e_p = e_h N_t (1 - f(E))$$

$$\text{where } e_h = v_{th,p} \sigma_p N_v e^{-(E_t - E_v)/KT}$$

Hole Emission Rate

Electron and Hole Capture and Emission

Recombination:

electron capture / hole capture

hole capture / electron capture

Generation:

hole emission / electron emission

electron emission / hole emission


Recycling of carriers into bands:

hole capture / hole emission

electron capture / electron emission

Carrier Concentrations after a “Perturbation”

$$\left. \frac{\partial p}{\partial t} \right|_{\text{Recombination}} = -c_p N_T p \quad \text{and} \quad \left. \frac{\partial p}{\partial t} \right|_{\text{Generation}} = c_p N_T p_o$$



Electron and Hole Capture and Emission

In steady state non-equilibrium, the number of electrons and holes are constant:

$$G - (c_e - e_e) = dn/dt = 0$$

$$G - (c_p - e_p) = dp/dt = 0$$

⑧ The net recombination/generation rate is,

This equation can be used to solve for $f'(E)$, the non-equilibrium fermi distribution function (which does NOT equal $f(E)$), then calculated as,